

MPO ▶ 700

13. Apr 2023


DATA SHEET

The omnidirectional robot **MPO-700** provides high-end manoeuvrability for robotic research projects. Its four independent wheels enable the **MPO-700** to move along true 3D-trajectories where the robot's orientation is not constrained by its X-Y-movement.

Different from other Kinematics, the **MPO-700** can drive along the front of a workbench or laboratory bench while permanently facing the workspace. This

significantly improves the work-flow and reduces the danger of collisions. Furthermore the robot is capable of moving through very narrow spaces and of navigating swiftly in difficult or crowded environments.

Additional modules such as manipulator arms, computers, sensors and actuators can be integrated easily to build a highly specialized and capable robotic system.



▶ PAYLOAD

400 kg

▶ WEIGHT

142 kg

▶ SENSORS

1 x Sick S300 Expert laser scanner
Options: 2nd Sick S300, diagonal mounting

▶ SPEED

max. 0.9 m/s

▶ UPTIME / CHARGE TIME

approx. 5 h / 4 h

▶ COMPUTER

Intel i5, 8 GB RAM, > 200 GB SSD, WLAN
Option: Intel i7, 16 GB RAM, > 400 GB SSD